

**Source:** Prestolite Electric Leece Neville Heavy Duty Systems

**Bulletin No:** TWB-0088 **Date:** December 16, 2022

**Models:** M93R3105SE wiring

**Subject:** Wiring Diagram




techservice@prestolite.com

### Wiring diagram for M93R3105SE

The starter motor is earth return (grounded).

The starter is fitted with a control relay (IMS). Switch / Ignition connection is made to control relay as shown below. Do NOT bypass or remove the control relay (IMS) from the starting system.



**Important:** The information contained in this bulletin is intended for use by trained, professional technicians who have the proper tools, equipment, and training to perform the required maintenance described above. This information is NOT intended for 'do-it-yourselfers', and you should not assume that this information applies to your equipment. If you have any questions regarding this information please visit our website at [www.prestolite.com](http://www.prestolite.com), or contact our technical service department at:

**Technical Service:** [techservice@prestolite.com](mailto:techservice@prestolite.com)

