

*This custom kit is manufactured by Snowbear Limited to fit:*

**GM FULL SIZE 1500, 2500 MOUNT ASSEMBLY**

**(4 x 4) YEAR 1981 to 1987**

**GM JIMMY, BLAZER & SUBURBAN MOUNT ASSEMBLY**

**(4 x 4) YEAR 1981 to 1991**

