

This custom kit is manufactured by Snowbear Limited to fit:

4 DR. FORD EXPLORER MOUNT ASSEMBLY
(4 x 4) YEAR 2002

NOTE: DO NOT PINCH WIRES YOU MUST UNCLIP WIRE FROM THE FRAME ON THE PASSENGER SIDE.

ITEM	DESCRIPTION	PART #	QTY.
1	CROSS MEMBER	5XM5	1
* NOT INCLUDED IN KIT, PURCHASE SEPARATELY			
2	L.H. SUPPORT	51125L	1
3	R.H. SUPPORT	51125R	1
4			
5	HEX BOLT 1/2-13 x 1 1/2	72510	4
6	LOCKING HEX NUT 1/2-13	72595	4
7	LOCKING HEX NUT 3/4-10	73595	2
8	3/4 FLAT WASHER	73580	4
9	HEX BOLT 3/4-10 x 4"	73535	2

