


GROUP:	31
FORM:	125-199AB
FILE:	Alternator Parts List Section
DATE:	May, 1988


MODEL	VOLTS	AMPS
Various See Chart		



MODEL NO.	SALES NO.	1 HSNG FRONT	2 ROTOR ASSEM	3 STATOR ASSEM	4 HSNG REAR	5 FAN	6 PULLEY	7 BRNG FRONT	8 BRNG REAR	9 SLIP RING	10 R.BRNG RET.	11 FIELD DIODE	12 RECT. BRIDGE
8EA2001FA	110-329	114-215	112-85	113-54	114-213	107-8		111-21	111-21	112-22	111-64	101-208	101-207
8EA2002FA	110-331	114-215	112-85	113-54	114-213	107-88		111-21	111-21	112-22	111-64	101-208	101-207
8EA2003FA		114-231	112-85	113-54	114-213	107-8	107-85	111-78	111-21	112-22	111-64	101-208	101-207
8EA2003FB		114-231	112-85	113-54	114-213	107-8	107-85	111-78	111-21	112-22	111-64	101-208	101-207
8EA2004FA	110-333	114-212	112-85	113-54	114-213	107-8		111-21	111-21	112-22	111-64	101-208	101-207
8EA2005KA	110-345	114-217	112-84	113-53	114-213	107-8	107-85	111-21	111-21	112-22	111-64	101-208	101-207
8EA2006KA	110-346	114-218	112-84	113-53	114-213	107-8		111-21	111-21	112-22	111-64	101-208	101-207
8EA2007KA	110-347	114-215	112-84	113-53	114-213	107-8		111-21	111-21	112-22	111-64	101-208	101-207
8EA2008KA	110-348	114-215	112-84	113-53	114-213	107-88		111-21	111-21	112-22	111-64	101-208	101-207
8EA2009KA	110-349	114-212	112-84	113-53	114-213	107-8		111-21	111-21	112-22	111-64	101-208	101-207
8EA2010KA	110-365	114-212	112-84	113-53	114-213	107-8	107-5	111-21	111-21	112-22	111-64	101-208	101-207
8EA2011NA	110-330	114-220	112-86	113-55	114-213	107-8		111-21	111-21	112-22	111-64	101-208	101-207
8EA2012NA	110-387	114-212	112-86	113-55	114-213	107-8		111-21	111-21	112-22	111-64	101-208	101-207
8EA2013NA	110-390	114-212	112-86	113-55	114-213	107-88	107-5	111-21	111-21	112-22	111-64	101-208	101-207
8EA2014FA	110-373	114-212	112-85	113-54	114-213	107-8	107-1	111-21	111-21	112-22	111-64	101-208	101-207
8EA2015FA	110-375	114-220	112-85	113-54	114-213	107-8		111-21	111-21	112-22	111-64	101-208	101-207
8EA2016FA	110-380	114-217	112-85	113-54	114-213	107-8	107-85	111-21	111-21	112-22	111-64	101-208	101-207
8EA2017NA	110-382	114-228	112-88	113-55	114-213	107-102		111-21	111-21	112-22	111-64	101-208	101-207
8EA2018NA	110-383	114-215	112-86	113-55	114-213	107-8		111-21	111-21	112-22	111-64	101-208	101-207
8EA2019DA		114-231	112-85	113-60	114-213	107-9		111-78	111-21	112-22	111-64	101-208	101-207
8EA2019DB		114-231	112-85	113-60	114-213	107-9		111-78	111-21	112-22	111-64	101-208	101-207

Important: The information contained in this bulletin is intended for use by trained, professional technicians who have the proper tools, equipment, and training to perform the required maintenance described above. This information is NOT intended for 'do-it-yourselfers', and you should not assume that this information applies to your equipment. If you have any questions regarding this information please visit our website at www.prestolite.com, or contact our technical service department at:

GROUP: 31
FORM: 125-199AB



MODEL NO.	SALES NO.	13 D+ STRAP	14 BRUSH ASSEM	15 FAN SPACER	16 WDRFF KEY	17 FELT GASKET	18 COVER ASSEM	19 CAPA-CITOR	20 AC TAP LUG	21 TERM MALE	22 VOLT. REG.	23 BLANK HSNQ	24 CABLE ASSEM
8EA2001FA	110-329	120-334	103-55	120-152	120-7	103-56	114-214		120-335		105-266		
8EA2002FA	110-331	120-334	103-55	120-152	120-7	103-56	114-214		120-335		105-266		
8EA2003FA			103-55	120-349	120-7	103-56	114-214		120-335		105-265		
8EA2003FB			103-55	120-349	120-7	103-56	114-214		120-335		105-265		
8EA2004FA	110-333	120-334	103-55	120-152	120-7	103-56	114-214		120-335		105-266		
8EA2005KA	110-345	120-334	103-55	120-152	120-7	103-56	114-214		120-335		105-265		
8EA2006KA	110-346	120-334	103-55	120-152	120-7	103-56	114-214		120-335		105-265		
8EA2007KA	110-347	120-334	103-55	120-152	120-7	103-56	114-214		120-335		105-266		
8EA2008KA	110-348	120-334	103-55	120-152	120-7	103-56	114-214		120-335		105-266		
8EA2009KA	110-349	120-334	103-55	120-152	120-7	103-56	114-214		120-335		105-266		
8EA2010KA	110-365	120-334	103-55	120-152	120-7	103-56	114-214		120-335		105-266		
8EA2011NA	110-330	120-334	103-55	120-152	120-7	103-56	114-214		120-335		105-266		
8EA2012NA	110-367	120-334	103-55	120-152	120-7	103-56	114-214		120-335		105-266		
8EA2013NA	110-390	120-334	103-55	120-152	120-7	103-56	114-214		120-335		105-266		
8EA2014FA	110-373	120-334	103-55	120-152	120-7	103-56	114-214		120-335		105-266		
8EA2015FA	110-375	120-334	103-55	120-152	120-7	103-56	114-214		120-335		105-266		16-131
8EA2016FA	110-380	120-334	103-55	120-152	120-7	103-56	114-214		120-335		105-265		
8EA2017NA	110-382	120-334	103-55	120-152		103-56	114-214		120-335		105-265		16-132
8EA2018NA	110-383	120-334	103-55	120-152	120-7	103-56	114-214		120-335		105-266		
8EA2019DA			103-55	120-349	120-7	103-56	114-214		120-335		105-265		
8EA2019DB			103-55	120-349	120-7	103-56	114-214		120-335		105-265		

Important: The information contained in this bulletin is intended for use by trained, professional technicians who have the proper tools, equipment, and training to perform the required maintenance described above. This information is NOT intended for 'do-it-yourselfers', and you should not assume that this information applies to your equipment. If you have any questions regarding this information please visit our website at www.prestolite.com, or contact our technical service department at:

GROUP:	31
FORM:	125-199AB

Important: The information contained in this bulletin is intended for use by trained, professional technicians who have the proper tools, equipment, and training to perform the required maintenance described above. This information is NOT intended for 'do-it-yourselfers,' and you should not assume that this information applies to your equipment. If you have any questions regarding this information please visit our website at www.prestolite.com, or contact our technical service department at: