

Source: Prestolite Electric Leece Neville Heavy Duty Systems


Bulletin No: TWB-0001 **Date:** December 16, 2021

Models: M97R3101SE

Subject: Wiring Diagram



techservice@prestolite.com



NOTE: Do not remove or bypass the control relay (IMS).

Terminal tightening torque values	
T30 (B+)	13.5 – 15.8 Nm
T50c (IGN / SW)	2 – 2.5 Nm

Important: The information contained in this bulletin is intended for use by trained, professional technicians who have the proper tools, equipment, and training to perform the required maintenance described above. This information is NOT intended for 'do-it-yourselfers', and you should not assume that this information applies to your equipment. If you have any questions regarding this information please visit our website at www.prestolite.com, or contact our technical service department at:

North & South America: Phone: +1 (844) 492-4062 | techservice@prestolite.com
Europe: Phone: +44 20 8231 1000 | techservice@prestolite.com

