

Source: Prestolite Electric Leece Neville Heavy Duty Systems

Bulletin No: TWB-0113 **Date:** July 23, 2024

Models: A34Q75

Subject: Wiring Diagram




techservice@prestolite.com

Wiring diagram for A34Q75 24V alternator

The alternator is an insulated return machine.

(B+ and B- insulated from alternator frame)

Terminal tightening torque values	
B+	6.2 – 7.9 Nm
B-	4.5 – 5.0 Nm
I	1.7 – 2.8 Nm
R (AC / W)	1.7 – 2.8 Nm



Important: The information contained in this bulletin is intended for use by trained, professional technicians who have the proper tools, equipment, and training to perform the required maintenance described above. This information is NOT intended for 'do-it-yourselfers', and you should not assume that this information applies to your equipment. If you have any questions regarding this information please visit our website at www.prestolite.com, or contact our technical service department at:

Technical Service: techservice@prestolite.com

